

HTTP-Request Shelly 4PRO

HTTP-Request Shelly 4PRO

HTTP-Request

HTTP-Request with Original-Firmware:

Enter in the address bar of the browser:

- switch **Shelly4PRO** relay ON: <http://192.168.xxx.xxx/relay/0?turn=on>
- switch **Shelly4PRO** relay OFF: <http://192.168.xxx.xxx/relay/0?turn=off>
- switch **Shelly4PRO** relay TOGGLE: <http://192.168.xxx.xxx/relay/0?turn=toggle>
- switch **Shelly4PRO** relay ON with Timer in s: <http://192.168.0.50/color/0?turn=on&white=20>
- switch **Shelly4PRO** relay OFF with Timer in s: <http://192.168.0.50/color/0?turn=on&white=20>

If an **authorization** is required:

- switch **Shelly4PRO** relay ON: <http://user:pass@192.168.xxx.xxx/relay/0?turn=on>
- user: user name to adjust
- pass: password to adjust

Channel assignment: channel 1: "0", channel 2: "1", channel 3: "2", channel 4: "3"; adjust accordingly!

The IP address must of course be adapted to the home network and the respective Shelly device.