

HTTP-Request Shelly 2.5

HTTP-Request Shelly 2.5

HTTP-Request with Original-Firmware:

Shelly 2.5 in Relay-Mode:

Enter in the address bar of the browser:

- switch **Shelly2.5** Relay ON: <http://192.168.xxx.xxx/relay/0?turn=on>
- switch **Shelly2.5** Relay OFF: <http://192.168.xxx.xxx/relay/0?turn=off>
- switch **Shelly2.5** Relay TOGGLE: <http://192.168.xxx.xxx/relay/0?turn=toggle>
- switch **Shelly2.5** Relay ON with Timer in s: <http://192.168.0.50/color/0?turn=on&white=20>
- switch **Shelly2.5** Relay OFF with Timer in s: <http://192.168.0.50/color/0?turn=on&white=20>

If an **authorization** is required:

- switch **Shelly2.5** Relay ON: <http://user:pass@192.168.xxx.xxx/relay/0?turn=on>
- user: user name to adjust
- pass: password to adjust

If the other channel is to be switched **via the actions** (internal):

- switch **Shelly2.5** Relay 1 ON: <http://http://localhost/relay/0?turn=on>
- switch **Shelly2.5** Relay 1 OFF: <http://http://localhost/relay/0?turn=off>
- switch **Shelly2.5** Relay 1 TOGGLE: <http://http://localhost/relay/0?turn=toggle>

Shelly2.5 in Roller Shutter-Mode:

Enter in the address bar of the browser:

- command **Shelly2.5** Roller Shutter CLOSE: <http://192.168.xxx.xxx/roller/0?go=close>
- command **Shelly2.5** Roller Shutter OPEN: <http://192.168.xxx.xxx/roller/0?go=open>
- command **Shelly2.5** Roller Shutter STOP: <http://192.168.xxx.xxx/roller/0?go=stop>

Control with runtime preset in sec.:

Enter in the address bar of the browser:

- CLOSE for 10 sec. duration: <http://192.168.xxx.xxx/roller/0?go=close&duration=10>
- OPEN for 10 sec. duration: <http://192.168.xxx.xxx/roller/0?go=open&duration=10>

Control with Position control in %:

Enter in the address bar of the browser:

- Position setting 75%: http://192.168.xxx.xxx/roller/0?go=to_pos&roller_pos=75

Channel assignment: channel 1: "0", channel 2: "1"; adjust accordingly!

The IP address must of course be adapted to the home network and the respective Shelly device.