


# Pair Plus H&T as an external sensor with TRV

Short instructions to pair PlusH&T as an external sensor:

Setting plusH&T in WEB-UI (press reset button to wake him up 3min,)



or in the App / home.shelly.cloud::

### Edit web hook ✕

Hooks in general, reduce battery life. Particularly, HTTPS hooks shortens battery life in half.

Set web hook name

Active time

Start time	End time
00 : 00	00 : 00

Condition:

temperature change

Available token replacements:

- `$(ev.tC)`
- `$(ev.tF)`

Active URIs

**SAVE**

Settings in the TRV (App/home.shelly.cloud):






Image not found or type unknown



if PlusH&T should be exclusive external sensor (without correction factor with TRV internal temperature)

Image not found or type unknown



and in WEB-UI:






Image not found or type unknown



if PlusH&T should be exclusive external sensor (without correction factor with TRV internal temperature)



**Addendum (as of September 27th, 2022) there is still a small error here if webhooks are generated via the app.**

**Go to WEB UI and und make sure the active time is set to default**

[Thumbnail failed](#) or type unknown